


HD



Communications Corp.

HD30728

81.36MHz 50W Class AB ISM Amplifier Mini-System

- ❖ Class AB 50W ISM amplifier mini-system
- ❖ 81.36MHz ISM band
- ❖ 50dB typical gain
- ❖ >55% typical DC efficiency
- ❖ Temperature-compensated bias
- ❖ 50 ohms input/output
- ❖ Thermal protection (auto reset)



The HD30728 is a Class AB 81.36MHz ISM amplifier mini-system, complete with power supply, heatsink, fan and thermal protection. It is excellent as a standalone driver for industrial, scientific, medical, or commercial applications. It utilizes a combination of three active device technologies for optimum performance and ruggedness.


Specifications				
$P_{out} = 50W, T_{ambient} = 25^{\circ}C, Z_{load} = 50\Omega$				
Parameter	Min	Typ	Max	Units
Freq. Range		81.36		MHz
P_{1dB}	50	60		W
Input Power		-3	0	dBm
Gain	47	50		dB
DC Efficiency		56		%
IRL		-30	-20	dB
f_2		-29	-24	dBc
f_3		-31	-26	dBc

Maximum Ratings	
Operation beyond these ratings will void warranty.	
Parameter	Value
Load Mismatch*	3:1
Ambient operating temperature	0°C to 45°C (non-condensing humidity)
Storage Temperature	-40°C to 85°C

*All phase angles, 50W forward power, 5 seconds max.

Electrical and Mechanical	
Connectors	Input/Output: SMA
V_{supply}	88-264VAC 47-63Hz, 1Φ, 2.0A
Dimensions	8.0 X 12.1 X 5.7 inch (203 X 307 X 145) (mm)

HD



Communications Corp.

HD30728

**81.36MHz 50W
Class AB ISM Amplifier
Mini-System**

Instructions for Amplifier Use

- 1) This amplifier requires unobstructed airflow from the front to the rear of the unit. Ensure sufficient clearance is allowed behind the amplifier for cooling air exhaust. Do not allow foreign objects to block or enter the air intake vents on the front panel.
- 2) Provide AC power to the amplifier as specified in the Electrical and Mechanical section on Page 1.
- 3) Connect a proper signal source to the RF IN connector, and desired load to the RF OUT connector. Torque connectors to industry standards for the type supplied with the amplifier.
- 4) Turn the amplifier on, and verify that the DC ON light illuminates. If it doesn't, verify that the fuse in the AC input connector is not blown. Replace fuse if necessary, as per the ratings specified on the rear panel.
- 5) Apply RF drive to achieve desired output level. Do not exceed 50W forward power.
- 6) To power down and disconnect the amplifier, first remove the RF drive, turn off the AC power, then remove the RF connections.

Note on thermal protection: The thermal protection circuit only removes power from the amplifier inside. When activated, the front panel DC ON light will still be illuminated, and the fan will still be moving air. If the light and fan are on, but there is no RF output, turn off the RF source, wait five minutes for the amplifier to cool, then apply RF again. The thermal protection is auto-resetting.

Contact us at sales@rfcomp.com with any questions, or for special options, testing requirements, and/or operating conditions not specified in this document.

Document Control

Revision	Date	Notes
A	7-29-2015	Production release.